



POLICE DEPARTMENT

FIELD UNIT INSPECTION REPORT
INTOXILYZER 5000EN

Technical Supervisor P. Zippo
Location 28 Pet.
Date of Inspection 5/27/08

Intoxilyzer Serial # 68-011473 Simulator Serial # DR 3556 Lot # 08010
1. .096
2. .095
3. .094
Diagnostic test ok
Breath hose heated ok
Printer check ok

Intoxilyzer Serial # 68-010779 Simulator Serial # DR 4153 Lot # 08010
1. .101
2. .101
3. .101
Diagnostic test ok
Breath hose heated ok
Printer check ok

REMARKS:

Selector changed in simulator # DR 3556.
Solution Lot # 08010, Intox. Ser# 68-011473.

Intox. Ser# 68-010779 reported o/p/s. Reported out of tolerance. Performed diagnostic + field inspection, instrument operating within normal tolerance. Returned to service. Hwy Dist. notified.

028 PCT
INTOXILYZER - ALCOHOL ANALYZER
MODEL 5000EN SN 68-010779
05/27/2008

DIAGNOSTIC TEST

15:35 EDT

PROM CHECK	PASSED
Z80 VER - G1776.12	
SLAVE 75_2240	
RAM CHECK	PASSED
TEMP CHECK	PASSED
PROCESSOR CHECK	
MOTOR CHECK	PASSED
EEPROM CHECK	PASSED
SERIAL NO. MATCH	PASSED
RANGE/STABILITY	PASSED
AUTO CAL STATUS	PASSED

RTC CHECK	PASSED
INTERNAL STD	PASSED

DIAGNOSTIC	PASSED
------------	--------

PRINTER CHECK	
ABCDEFGHIJKLMNORSTUVWXYZ	
0123456789	

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679 - 1990

028 PCT
INTOXILYZER - ALCOHOL ANALYZER
MODEL 5000EN SN 68-010779
05/27/2008

TEST	%BrAC	TIME
AIR BLANK	.000	15:36EDT
CAL. CHECK	.101	15:37EDT
AIR BLANK	.000	15:37EDT
CAL. CHECK	.101	15:37EDT
AIR BLANK	.000	15:37EDT
CAL. CHECK	.101	15:38EDT
AIR BLANK	.000	15:38EDT
NO. OF SAMPLES:	03	
MEAN:	.1010	
STD. DEVIATION:	.0000000	

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty S. Ct.). WWW.NEYORKLEGALDEFENSE.COM - (212) 679 - 1990

SN 68-010779

VERSION G1776.12

SLAVE 75 2240

DATE 05/27/2008

TIME 15:40 EDT

1234567890ABCDEFGHIJKLMNOPQRSTUVWXYZ-=[]; ,./<>?abcdefghijklmnop
pqrstuvwxyz!@#%&^*()

028 PCT

** CURRENT INSTRUMENT SETUP **

SETUP WORD = 0x0029

STD TEST = CUST 1

3 DIGITS ON? Y/N = TRUE

PRELIM RES? Y/N = FALSE

DATA ENTRY? Y/N = TRUE

PRINT INHIB? Y/N = FALSE

SAMPLE CAPT? Y/N = FALSE

INT STDS? Y/N = FALSE

PRINT VOLUME Y/N = FALSE

SETUP WORD 2 = 0x0000

STANDBY TIMEOUT = 030

CALIBRATION TYPE = WET BATH

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679 - 1990

nty. Ser. # 68-010779

Cal. ck- out of tolerance reported on S/17108, not in lab.

Handwritten signature or initials, possibly "MS".

Handwritten initials "FO".

Handwritten initials "FO".

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al., Case No. 100220/2012 (N.Y. Cty S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990