



POLICE DEPARTMENT

FIELD UNIT INSPECTION REPORT  
INTOXILYZER 5000EN

Technical Supervisor P. Zippo (PM)  
Location 28 Pct.  
Date of Inspection 6/10/08

Intoxilyzer Serial # 68-011473 Simulator Serial # DR3556 Lot # 08010  
1. .099  
2. .098  
3. .098  
Diagnostic test OK  
Breath hose heated OK  
Printer check OK

Intoxilyzer Serial # 68-010779 Simulator Serial # DR4153 Lot # 08010  
1. .103  
2. .103  
3. .103  
Diagnostic test OK  
Breath hose heated OK  
Printer check OK

REMARKS:

Found Intox. Ser. #68-010779 powered off. Sim. Ser. # DR4153 operating. Powered on Intox. Ser. #68-010779 for field inspection. Performed field inspection, Intox. Ser. #68-010779 operating properly. (PM)

Obtained by Perlmutter, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al., Case No. 100220/02 (N.Y. City S. Ct.). WWW.NYORKLEGALDEFENSE.COM - (212) 679-1990

028 PCT  
INTOXILYZER - ALCOHOL ANALYZER  
MODEL 5000EN SN 68-010779  
06/10/2008

DIAGNOSTIC TEST 16:16 EDT

PROM CHECK	PASSED
Z80 VER - G1776.12	
SLAVE 75_2240	
RAM CHECK	PASSED
TEMP CHECK	PASSED
PROCESSOR CHECK	
MOTOR CHECK	PASSED
EEPROM CHECK	PASSED
SERIAL NO. MATCH	PASSED
RANGE/STABILITY	PASSED
AUTO CAL STATUS	PASSED

RTC CHECK	PASSED
INTERNAL STD	PASSED

DIAGNOSTIC	PASSED
------------	--------

PRINTER CHECK	
ABCDEFGHIJKLMNOPQRSTUVWXYZ	
0123456789	

Obtained by Perlmutter & McGuinness, P.C. in Law Office of Adam D. Perlmutter, P.C. v. NYPD, et al.,  
Case No. 100220/2012 (N.Y. Cty S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990

028 PCT  
INTOXILYZER - ALCOHOL ANALYZER  
MODEL 5000EN SN 68-010779  
06/10/2008

TEST	%BrAC	TIME
AIR BLANK	.000	16:17EDT
CAL. CHECK	.103	16:18EDT
AIR BLANK	.000	16:18EDT
CAL. CHECK	.103	16:18EDT
AIR BLANK	.000	16:19EDT
CAL. CHECK	.103	16:19EDT
AIR BLANK	.000	16:19EDT
NO. OF SAMPLES:	03	
MEAN:	.1030	
STD. DEVIATION:	.0000000	

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,  
Case No. 100220/2012 (N.Y. Cty S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679 - 1990

SN 68-010779  
SLAVE 75\_2240  
DATE 06/10/2008  
1234567890ABCDEFGHIJKLMNPOQRSTUVWXYZ-=[ ]; ,./<>?abcdefghijklmnop  
pqrstuvwxyz!@#\$%^\*()

VERSION G1776.12

TIME 16:20 EDT

028 PCT

\*\* CURRENT INSTRUMENT SETUP \*\*

SETUP WORD = 0x0029  
STD TEST = CUST 1  
3 DIGITS ON? Y/N = TRUE  
PRELIM RES? Y/N = FALSE  
DATA ENTRY? Y/N = TRUE  
PRINT INHIB? Y/N = FALSE  
SAMPLE CAPT? Y/N = FALSE  
INT STDS? Y/N = FALSE  
PRINT VOLUME Y/N = FALSE  
SETUP WORD 2 = 0x0000

STANDBY TIMEOUT = 030

CALIBRATION TYPE = WET BATH

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,  
Case No. 100220/2012 (N.Y. Cty S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679 - 1990