



POLICE DEPARTMENT

FIELD UNIT INSPECTION REPORT
INTOXILYZER 5000EN

Technical Supervisor P. Zippo
Location 45 Pct.
Date of Inspection 6/27/08

Intoxilyzer Serial # 68-010779 Simulator Serial # DL3561 Lot # 08070

- 1. .101
- 2. .103
- 3. .103
- Diagnostic test OK
- Breath hose heated OK
- Printer check OK

Intoxilyzer Serial # 68-01196 Simulator Serial # DR2679 Lot # 08070

- 1. .101
- 2. .103
- 3. .102
- Diagnostic test OK
- Breath hose heated OK
- Printer check OK

REMARKS:

Intox. Ser. # 68-010780 o/o/s due to Int. Std. / Diagnostic fail. Replaced with Intox. Ser. # 68-010779. Changed 10% Ref EtOH Sol'n. in Sim. Ser. # DR3561 to Lot # 08070, changed 10% Ref. EtOH Sol'n. in Sim. Ser. # DR2679 to Lot # 08

Intox. Ser. # 68-01196 o/o/s due to out of tolerance. Reset target value from .080 to .100. Performed Diagn. / Cal. ck. - Field Inspection. Ret'd back to service.

Signed - PO Phillips (Signature)

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al., Case No. 1002207212 (N.Y. Cty. S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990

045 PCT
INTOXILYZER - ALCOHOL ANALYZER
MODEL 5000EN SN 68-010779
06/27/2008

DIAGNOSTIC TEST 18:15 EDT

PROM CHECK	PASSED
Z80 VER - G1776.12	
SLAVE 75_2240	
RAM CHECK	PASSED
TEMP CHECK	PASSED
PROCESSOR CHECK	
MOTOR CHECK	PASSED
EEPROM CHECK	PASSED
SERIAL NO. MATCH	PASSED
RANGE/STABILITY	PASSED
AUTO CAL STATUS	PASSED

RTC CHECK	PASSED
INTERNAL STD	PASSED

DIAGNOSTIC	PASSED
------------	--------

PRINTER CHECK	
ABCDEFGHIJKLMN OPQRSTUVWXYZ	
0123456789	

Obtained by Perlmutter & McGuinness, P.C. Law Office of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990

045 PCT
INTOXILYZER - ALCOHOL ANALYZER
MODEL 5000EN SN 68-010779
06/27/2008

TEST	%BrAC	TIME
AIR BLANK	.000	18:16EDT
CAL. CHECK	.101	18:16EDT
AIR BLANK	.000	18:16EDT
CAL. CHECK	.103	18:17EDT
AIR BLANK	.000	18:17EDT
CAL. CHECK	.103	18:17EDT
AIR BLANK	.000	18:18EDT
NO. OF SAMPLES:	03	
MEAN:	.1023	
STD. DEVIATION:	.0011531	

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEYORKLEGALDEFENSE.COM - (212) 679-1990

SN 68-010779

VERSION G1776.12

SLAVE 75 2240

DATE 06/27/2008

TIME 18:19 EDT

1234567890ABCDEFGHIJKLMNPOQRSTUVWXYZ--[]; ,./<>?abcdefghijklmnop
qrstuvwxyz!@#\$%^*()

045 PCT

** CURRENT INSTRUMENT SETUP **

SETUP WORD = 0x0029

STD TEST = CUST 1

3 DIGITS ON? Y/N = TRUE

PRELIM RES? Y/N = FALSE

DATA ENTRY? Y/N = TRUE

PRINT INHIB? Y/N = FALSE

SAMPLE CAPT? Y/N = FALSE

INT STDS? Y/N = FALSE

PRINT VOLUME Y/N = FALSE

SETUP WORD 2 = 0x0000

STANDBY TIMEOUT = 030

CALIBRATION TYPE = WET BATH

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990

SN 68-010779
SLAVE 75_2240
DATE 06/27/2008
INVALID TEST
CHECK AMBIENT CONDITIONS

VERSION G1776.12

TIME 10:23 EDT

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990

SN 68-010779
SLAVE 75_2240
DATE 06/27/2008
INVALID TEST
INSTRUMENT RANGE EXCEEDED

VERSION G1776.12

TIME 09:50 EDT

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990

SN 68-010779
SLAVE 75_2240
DATE 06/27/2008
INVALID TEST
CHECK AMBIENT CONDITIONS

VERSION G1776.12

TIME 09:52 EDT

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990

SN 68-010779
SLAVE 75 2240
DATE 06/27/2008
INVALID TEST
INSTRUMENT RANGE EXCEEDED

VERSION G1776.12

TIME 10:01 EDT

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990

SN 68-010779
SLAVE 75 2240
DATE 06/27/2008
INVALID TEST
CHECK AMBIENT CONDITIONS

VERSION G1776.12

TIME 10:07 EDT

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990

SN 68-010779
SLAVE 75_2240
DATE 06/27/2008
INVALID TEST
CHECK AMBIENT CONDITIONS

VERSION G1776.12

TIME 10:17 EDT

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990

NYPD LAB
INTOXILYZER - ALCOHOL ANALYZER
MODEL 5000EN SN 68-010779
06/27/2008

DIAGNOSTIC TEST 10:19 EDT

PROM CHECK PASSED
Z80 VER - G1776.12
SLAVE 75_2240
RAM CHECK PASSED
TEMP CHECK PASSED
PROCESSOR CHECK
MOTOR CHECK PASSED
EEPROM CHECK PASSED
SERIAL NO. MATCH PASSED
RANGE/STABILITY PASSED
AUTO CAL STATUS PASSED

RTC CHECK PASSED
INTERNAL STD PASSED

DIAGNOSTIC PASSED

PRINTER CHECK
ABCDEFGHIJKLMNOPQRSTUVWXYZ
0123456789

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990

NYPD LAB
INTOXILYZER - ALCOHOL ANALYZER
MODEL 5000EN SN 68-010779
06/27/2008

TEST	%BrAC	TIME
AIR BLANK	.000	10:40EDT
CAL. CHECK	.098	10:40EDT
AIR BLANK	.000	10:40EDT
CAL. CHECK	.098	10:41EDT
AIR BLANK	.000	10:41EDT
CAL. CHECK	.099	10:41EDT
AIR BLANK	.000	10:42EDT
NO. OF SAMPLES:	03	
MEAN:	.0983	
STD. DEVIATION:	.0005742	

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEYORKLEGALDEFENSE.COM - (212) 679-1990

NYPD LAB
INTOXILYZER - ALCOHOL ANALYZER
MODEL 5000EN SN 68-010779
06/27/2008

DIAGNOSTIC TEST 10:16 EDT

PROM CHECK PASSED
Z80 VER - G1776.12
SLAVE 75_2240
RAM CHECK PASSED
TEMP CHECK PASSED
PROCESSOR CHECK
MOTOR CHECK PASSED
EEPROM CHECK PASSED
SERIAL NO. MATCH PASSED
RANGE/STABILITY PASSED
AUTO CAL STATUS PASSED

RTC CHECK PASSED
INTERNAL STD PASSED

DIAGNOSTIC PASSED

PRINTER CHECK
ABCDEFGHIJKLMNOPQRSTUVWXYZ
0123456789

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990

045 PCT
INTOXILYZER - ALCOHOL ANALYZER
MODEL 5000EN SN 68-010779
06/27/2008

DIAGNOSTIC TEST 18:15 EDT

PROM CHECK PASSED
Z80 VER - G1776.12
SLAVE 75_2240

RAM CHECK PASSED
TEMP CHECK PASSED
PROCESSOR CHECK
MOTOR CHECK PASSED
EEPROM CHECK PASSED
SERIAL NO. MATCH PASSED
RANGE/STABILITY PASSED
AUTO CAL STATUS PASSED

RTC CHECK PASSED
INTERNAL STD PASSED

DIAGNOSTIC PASSED

PRINTER CHECK
ABCDEFGHIJKLMNORSTUVWXYZ
0123456789

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEWYORKLEGALDEFENSE.COM - (212) 679-1990

045 PCT
INTOXILYZER - ALCOHOL ANALYZER
MODEL 5000EN SN 68-010779
06/27/2008

TEST	%BrAC	TIME
AIR BLANK	.000	18:16EDT
CAL. CHECK	.101	18:16EDT
AIR BLANK	.000	18:16EDT
CAL. CHECK	.103	18:17EDT
AIR BLANK	.000	18:17EDT
CAL. CHECK	.103	18:17EDT
AIR BLANK	.000	18:18EDT
NO. OF SAMPLES:	03	
MEAN:	.1023	
STD. DEVIATION:	.0011531	

Obtained by Perlmutter & McGuinness, P.C. in Law Offices of Adam D. Perlmutter, P.C. v. NYPD, et al.,
Case No. 100220/2012 (N.Y. Cty. S. Ct.). WWW.NEYORKLEGALDEFENSE.COM - (212) 679-1990